



How to upgrade Artist 24Pro's code?

1. Please install the latest Artist 24Pro's driver until complete then open tablet setting and make sure you can test pen pressure on it.
2. If yes, please save and extract it.
3. Open the folder then run “UgeeBootLoader.exe” then click “OneKeyUpdate” button.



4. If you can see “Burn success”, please click “X” button to exit.

